

All transponders must be located on the rear sub frame, where the rear control arms meet.

ALONG WITH THESE SCDRA Rules:

<http://www.scdranortheast.com/rules.html>